

Headboard Wall Mount, No Legs – Mounting Instructions

DRAWING "A"

1. Measure the distance from the top of the headboard to the top of the angle of the wooden wall bracket attached to the back of the headboard. This is where the top of the angle of the enclosed wooden wall bracket is to be placed.
2. Determine the height on your wall that you want the top of the headboard to be.
3. Use stud finder to find studs in wall.
4. Measure down from the top of where the headboard is to be placed on the wall, the distance determined in Line #1 and make small marks on the wall where the wooden wall bracket angle is to be placed.
5. Drill holes through the wooden wall bracket where it will be attached to the wall studs.
6. Secure wooden wall bracket to the wall studs with screws.

DRAWING "B"

7. Set the headboard onto the wooden wall bracket that is screwed to the wall.

PROVIDED FOR YOU

Wood screws
Wooden wall bracket

TOOLS REQUIRED

T-25 Torque bit
Drill
Level
Stud finder
Measuring tape

DRAWING "A"



DRAWING "B"

